







STRIPPING CABLE END

Step 1		Mount angle bracket to car guiderail by tightening beam clamps. (See "Parts Identification" - other side.)																
Step 2	<p>Select clamp size appropriate to the size of Whisper-flex cable that is to be stripped. Slide clamp ends into free arm of angle bracket.</p> <table border="1" data-bbox="289 483 1272 578"> <tr> <td>Whisper-Flex Size:</td> <td>WF075</td> <td>WF15</td> <td>WF20</td> <td>WF25</td> <td>WF30</td> <td>WF35</td> <td>WF40</td> </tr> <tr> <td>Clamp Size:</td> <td>B2030</td> <td>B2032</td> <td>B2033</td> <td>B2034</td> <td>B2035</td> <td>B2036</td> <td>B2037</td> </tr> </table>		Whisper-Flex Size:	WF075	WF15	WF20	WF25	WF30	WF35	WF40	Clamp Size:	B2030	B2032	B2033	B2034	B2035	B2036	B2037
Whisper-Flex Size:	WF075	WF15	WF20	WF25	WF30	WF35	WF40											
Clamp Size:	B2030	B2032	B2033	B2034	B2035	B2036	B2037											
Step 3		Clamp one end of Whisper-Flex® Compensating Cable on the free arm of the angle bracket to hold it securely while the jacket is being removed. Clamp it such that approximately 3-4 inches (7.6-10.0 cm) of the free end is exposed. NOTE: Cable shown in photos is white for picture clarity.																
Step 4		Using the cable jacket cutter, score the circumference of the jacket far enough from the cable end to leave 1½ chain links free.																
Step 5		Make sure the jacket has been cut through to the depth of the actual chain. Bend back the top of the Whisper-Flex® Cable and run the utility knife along the scoring groove made by the cable jacket cutter.																
Step 6		With the utility knife, make a cut lengthwise from the groove created in step 4 to the end of the cable. Make sure the jacket has been cut through to the depth of the actual chain.																
Step 7		Grasp the jacket at one edge of the lengthwise cut with the nippers and pull back, away from the chain. Repeat this step for the other edge of the cut. Repeat steps 5 through 7 as needed until the 1½ links are completely free of the jacket.																



KIT CONTENTS:

- Angle mounting bracket
- Seven (7) clamps
- Nippers
- Utility knife
- Cable jacket cutter
- Hacksaw
- Gloves
- Carrying case.

OTHER TOOLS REQUIRED

(not included):

- 3/4" Wrench
- Flathead screwdriver



REPLACEMENT PARTS?

Call Draka EP Customer Service at 1-800-972-6000 (USA) or 1-800-263-8279 (Canada).

Draka EP Order No.	Description
36-190	Utility Knife
36-191	Cable Jacket Cutter
36-192	Nippers
36-193	Hacksaw
36-194	Gloves

←←To cut to length, see other side.

CUTTING TO LENGTH

Step 1		Mark location to cut off excess cable length. If under the car, be sure to leave enough length to form a safety loop. (Ref. <i>Whisper-Flex® Compensating Cable Installation Guide</i> at www.draka-ep.com or call Draka EP Customer Service at 1-252-972-6000.)
Step 2		Remove the two bolts that join the free arm of the angle bracket and gusset to secure the Whisper-Flex cable in a horizontal direction. Rotate the free arm ¼ turn and replace the bolts.
Step 3		Using the hacksaw, cut off excess Whisper-Flex Cable at the mark made in step 1.

To receive compensating cable in the field with one end already stripped for termination, order Draka Elevator Products' **Whisper-Flex® Cable stripping service**. Draka EP will remove the jacket and filler material from 1½ links at one end of a length of Whisper-Flex Compensating Cable.

Call Draka EP Customer Service at **1-877-DRAKAEP** (1-877-372-5237) in the USA or **1-800-263-8279** in Canada.

Ask for **WFSTRIP1.5L**.

Parts Identification

